

Schwinn Airdyne AD6 100250

Reference Number	Part #	Description	Notes
1	1000514268	CONSOLE ASSEMBLY, FOR AD6	
10	1000514266	FOOT PEG ASSEMBLY RIGHT	
11	1000514267	FOOT PEG ASSEMBLY LEFT	
12	1000514154	POP PIN MECHANICAL ASSEMBLY	
13	1000514259	REAR STABILIZER	
14	1000514265	REAR STABILIZER END CAP	
15	1000511113	STABILIZER FOOT ASSEMBLY	
16	1000514258	FRONT STABILIZER	
17	1000514264	FRONT STABILIZER END CAP	
18	1000511114	TRANSPORT WHEEL ASSEMBLY	
19	1000511459	CABLE EXTENSION	
2	1000514269	ASSY, CONSOLE SUPPORT	
20	1000514220	DOCUMENT KIT, SCH AD6	
21	1000514221	USER ASSY HRDW - SCH AD6	
22	1000514222	RIGHT SHROUD / DECAL ASSY	
23	1000511842	LEFT SHROUD / DECAL ASSY (2015)	
24	1000511194	SVC KIT, HARDWARE, CRANK WELDMENT	
25	1000511257	SERVICE KIT, CRANK ASSY, RIGHT	
26	1000511256	SERVICE KIT, CRANK ASSY, LEFT	
27	1000514261	CRANK COVER	
28	1000511259	SERVICE KIT, CONNECTOR ARM ASSY	
29	1000514263	HTD BELT MAIN PULLEY	
3	1000511261	SERVICE KIT, BOTTLE HOLDER	
30	1000514256	MAIN PULLEY ASSEMBLY	
31	1000511260	SERVICE KIT, FOOT STEP PAD	
32	1000514250	SEAT RAIL BUSHING	
33	1000511258	SERVICE KIT, ARM PIVOT ASSY	
34	1000514257	IDLER PULLEY ASSEMBLY	
35	1000513662	SERVICE KIT, IDLER PULLEY HARDWARE	
36	1000514262	6J BELT	
37	1000511458	CABLE ASSY SPEED SENSOR	
38	1000514260	SPEED SENSOR MOUNT	
39	1000514271	WELDMENT FAN CAGE RIGHT	
4	1000514252	SEAT ASSEMBLY	
40	1000514270	WELDMENT FAN CAGE LEFT	
41	1000514251	FAN ASSEMBLY	
42	1000511443	SVC KIT, FAN CLIPS AND HDW, AD6	
43	1000511905	SERVICE KIT, FAN CAGE CLIP	
5	1000514249	SEAT POST WELDMENT	
6	1000514254	HANDLE BAR ASSEMBLY RIGHT	
7	1000514255	HANDLE BAR ASSEMBLY LEFT	
8	1000514152	Pedal Assembly-Right	
9	1000514153	Pedal Assembly-Left	
900	1000511115	SHROUD HARDWARE	
901	1000511185	SVC KIT, SPINDLE REMOVAL AND RPLC	
902	1000511650	STRAP,TRNSPRT&IMMOBILIZE,50X400mm	

TITLE EXP VIEW DWG- SCHWINN AD6 AIRDYNE BIKE			
DESIGNED BY R. PETERSON	DOC. PART NO. 100250-W	PRODUCT SKU NO. 100250	REV. H
DATE 02/09/2022			



